

Welke snelsluiting op welke schoen:

No Risk

Model

No Risk Sprinter Laag ATOP 1208.10 S3
No Risk Ultra 1047.41 ATOP Metaalvrij S3
No Risk Eiger ATOP 1025.27 S3
No Risk Centaurus 1049.31 ATOP Metaalvrij S1P
No Risk Pegasus 1249.31 ATOP S1P
No Risk Mirage 1249.20 S1P
No Risk Athletic Mid MOZ Black 1019.25 S7L
No Risk X-treme Low FLS Grey 1557.06 S3L
No Risk X-treme Mid FLS Grey 1057.06 S3L
No Risk Athletic Low FLS Grey Blue 1219.16 S3L
No Risk Athletic Low MOZ Black 1219.25

Snelsluiting

MOZ repair set shoe LOW
MOZ repair set boot HIGH
MOZ repair set Eiger
MOZ repair set boot HIGH
MOZ repair set shoe LOW
MOZ repair set shoe LOW
MOZ repair set boot HIGH
MOZ repair set shoe LOW
MOZ repair set boot HIGH
MOZ repair set shoe LOW
MOZ repair set shoe LOW